

---

## AQT-290

---

### POWERFLO SERIES

---



**AQUATROL**™  
CONTROL VALVES




## TABLE OF CONTENTS

General Residential Installation	4
AQT-290 Timer Start-up Setting Procedures	5
AQT-290 Timer Delay Start-up Setting Procedures	6
Regeneration Cycle Program Setting Procedures	7
Downflow Diagrams	8
Dimensional Drawings	11
Body Valve Assembly	12
Body Valve Assembly Parts List	13
Upper Control Drive Assembly	14
Upper Control Drive Assembly Parts List	15
Lower Control Drive Assembly	16
Lower Control Drive Parts List	17
170 Brine System Assembly	18
170 Brine System Assembly Parts List	19
Troubleshooting	20
Wiring Diagram	22
Notes	23



Water Pressure	Minimum 25 PSI
Electrical Supply	Uninterrupted AC. Check voltage compatibility
Existing	Free of any deposits or build-ups inside pipes
Softener	Locate close to drain and connect according to plumbing codes
Bypass Valves	Always provide for bypass valve if unit is not equipped with one

CAUTION	
	Do not exceed 120 PSI water pressure
	Do not exceed 100°F water temperature
	Do not subject unit to freezing conditions

### Installation Instructions

1. Place the softener tank where you want to install the unit making sure the unit is level and on a firm base.  
(Maximum 4 feet apart for twin units.)
2. All plumbing should be done in accordance with local plumbing codes. The pipe size for the drain line should be the same size as the drain line flow control female connection. Water meters are to be installed on soft water outlets. Twin units with (1) one meter shall be installed on common soft water outlets of units.
3. Solder joints near the drain must be done prior to connecting the Drain Line Flow Control fitting. Leave at least 6" between the DLFC and solder joints when soldering when the pipes are connected on the DLFC. Failure to do this could cause interior damage to the DLFC.
4. Teflon tape is the only sealant to be used on the drain fitting. The drain from twin units may be run through a common line.
5. Make sure that the floor is clean beneath the salt storage tank and that it is level
6. Place approximately 1" of water above the grid plate (if used) in your salt tank. Salt may be place in the unit at this time.
7. On units with by-pass, place in by-pass position. Turn on main water supply. Open a cold soft water tap nearby and let run a few minutes or until the system is free from foreign material (usually solder) that may have resulted from the installation.
8. Place the by-pass in service position.
9. Manually index the softener control into "service" position and let water flow into the mineral tank. When water flow stops, open a cold water tap nearby and let run until air pressure is relieved.
10. Electrical: All electrical connections must be connected according to codes. Use electrical conduit if applicable. See Wiring Diagram section for more information.
11. Plug into power supply

### How To Set Days On Which Water Conditioner Is To Regenerate:


Rotate the skipper wheel until the number "1" is at the red pointer.  
Set the days that regeneration is to occur by sliding tabs on the skipper wheel outward to expose trip fingers.  
Each tab is one day. Finger at red pointer is tonight.  
Moving clockwise from the red pointer, extend or retract fingers to obtain the desired regeneration schedule.

### How To Set The Time Of Day:

Press and hold the blue button in to disengage the drive gear.  
Turn the large gear until the actual time of day is at the time of day pointer.  
Release the blue button to again engage the drive gear.


### How To Manually Regenerate Your Water Conditioner At Any Time:

Turn the manual regeneration knob clockwise.  
This slight movement of the manual regeneration knob engages the program wheel and starts the regeneration program.  
The black center knob will make one revolution in the following approximately three hours and stop in the position shown in the drawing.  
Even though it takes three hours for this center knob to complete one revolution, the regeneration cycle of your unit might be set only one half of this time.  
In any event, conditioned water may be drawn after rinse water stops flowing from the water conditioner drain line.




### How To Adjust Regeneration Time:

1. Disconnect the power source.
2. Locate the three screws behind the manual regeneration knob by pushing the blue button in and rotating the 24 hour dial until each screw appears in the cut out portion of the manual regeneration knob.
3. Loosen each screw slightly to release the pressure on the time plate from the 24 hour gear.
4. Locate the regeneration time pointer on the inside of the 24 hour dial in the cut out.
5. Turn the plate so the desired regeneration time aligns next to the raised arrow.
6. Push the blue button in and rotate the 24 hour dial. Tighten each of the three screws.
7. Push the blue button and locate the pointer one more time to ensure the desired regeneration time is correct.
8. Reset the time of day and restore power to the unit.



## AQT-290 Timer Delay

### Start-up Setting Procedures



#### NOTE:

To set meter capacity rotate manual knob 1-360° revolution to set the gallons.

### Typical Programming Procedure

Calculate the gallon capacity of the system, subtract the necessary reserve requirement and set the gallons required by lifting the gallon dial and rotating it so that the number of gallons required is aligned with the white dot on the program wheel gear. Release and check for firm engagement with gear.

Note: To set meter capacity at initial start-up, either:

1. Rotate the manual regeneration knob one full revolution.
  - or
  2. Rotate the program wheel manual clockwise and align white dot with capacity arrow.
- This procedure must be followed any time the program wheel setting is changed.

### How To Set The Time Of Day:


Press and hold the white button in to disengage the drive gear.  
Turn the large gear until the actual time of day is opposite of the time of day pointer.  
Release the white button to again engage the drive gear.

### How To Manually Regenerate Your Water Conditioner At Any Time:

Turn the manual regeneration knob clockwise one "click".  
This slight movement of the manual regeneration knob engages the program wheel and starts the regeneration program.  
The black center knob will make one revolution in the following approximately three hours and stop in the position shown in the drawing.  
Even though it takes three hours for this center knob to complete one revolution, the regeneration cycle of your unit might be set for only on half of this time.  
In any event, conditioned water may be drawn after rinse water stops flowing from the water conditioner drain line.

### Immediate Regeneration Times:

These timers do not have a 24 hour gear. Setting the gallons on the program wheel and manual regeneration procedure are the same as previous instructions.



### How To Set The Regeneration Cycle Program:

The regeneration cycle program on your water conditioner has been factory preset, however, portions of the cycle or program may be lengthened or shortened in time to suit local conditions.

### Timer Setting Procedure:

#### How To Change The Length Of The Backwash Time:

The program wheel as shown in the drawing is in the service position. As you look at the numbered side of the program wheel, the group of pins starting at zero determines the length of time your unit will backwash.

**For example:** If there are six pins in this section, the time of backwash will be 12 min. (2 min. per pin). To change the length of backwash time, add or remove pins as required. The number of pins times two equals the backwash time in minutes.

#### How To Change The Length Of Brine And Rinse Time:

The group of holes between the last pin in the backwash section and the second group of pins determines the length of time that your unit will brine and rinse (2 min. per hole).

To change the length of brine and rinse time, move the rapid rinse group of pins to give more or fewer holes in the brine and rinse section. Number of holes times two equals brine and rinse time in minutes.

#### How To Change The Length Of Rapid Rinse:

The second group of pins on the program wheel determines the length of time that your water conditioner will rapid rinse (2 min. per pin)

To change the length of refill time, add or remove pins at the higher numbered end of this section as required. The number of pins times two equals the rapid rinse time in minutes.


#### How To Change The Length Of Brine Tank Refill Time:

The second group of holes in the program wheel determines the length of time that your water conditioner will refill the brine tank (2 min. per hole).

To change the length of refill time, move the two pins at the end of the second group of holes as required.


The regeneration cycle is complete when the outer microswitch is tripped by the two pin set at the end of the brine tank refill section.

The program wheel, however, will continue to rotate until the inner micro-switch drops into the notch on the program wheel.



### 1) Service Position


Hard water enters unit at valve inlet and flows down through the mineral in the mineral tank. Conditioned water enters center tube through the bottom distributor, then flows up through the center tube, around the piston, and out the outlet of the valve.



### 2) Backwash Position


Hard water enters unit at valve inlet - flows through service adapter for bypass, and up through coupling to regenerating valve piston - down the center tube - through the bottom distributor and up through the mineral - around the piston and out the drain line. If optional no hard water bypass piston is used water flow to outlet is prevented by an extended section of the service piston which closes the outlet port from bypass water until the end of rapid rinse.






### 3) Brine Position

Hard water enters unit at valve inlet - flows up into injector housing and down through nozzle and orifice to draw brine from the brine tank - brine flows down through mineral and enters the center tube through bottom distributor - flows up through center tube - around the piston and out through the drain line.




### 4) Slow Rinse Position

Hard water enters unit at valve inlet - flows up into injector housing and down through nozzle and around orifice - around the piston - down through mineral - enters center tube through bottom distributor - flows up through center tube - around piston and out through the drain line.






### 5) Rapid Rinse


Hard water flows through the regenerating valve directly down through the mineral into the bottom distributor and up through the center tube.




### 6) Slow Rinse Position

Hard water enters unit at valve inlet - flows up into injector housing and down through nozzle and around orifice - around the piston - down through mineral - enters center tube through bottom distributor - flows up through center tube - around piston and out through the drain line.





No Hard Water Bypass Piston




Item No.	Quantity	Part No.	Description
1	1	A-14749-01	Body, Valve Upper, AQT 290
2	1	A-11208	O-ring, Body Seal, Base
3	2	A-11710	O-ring, Body Seal, Riser Tube
4	1	A-14751	Coupling, AQT-290 Upper-Lower
5*	1		DLFC Button/Washer
6	1	A-60699-00	DLFC Brass, F 3/4" X F 3/4", No Washer
7	1	A-14750-01	Body, Valve Lower, 2", AQT-290
8	1	A-13577	O-ring, Body, Riser Tube
9	1	A-13575	O-ring, Body, Base
10	2	A-11224	Screw, Valve Mounting
11	1	A-12248	Cap, 1" NPT
12	1	A-60090-HF	Piston HW, Assy, AQT-275 & AQT-290 Upper
13	1	A-60121-10	Seals & Spacers, Kit, AQT275 & AQT-290 Upper
14	1	A-60128	Seals & Spacers, Kit, AQT-290 Lower
15	1	A-60103	Piston HW, Assy, AQT-290 Lower
16	1	A-60104	Piston NH, Assy, AQT-290 Lower

* DLFC Button / Washer Options	
A-17943	DLFC Washer Flow 8 gpm
A-17944	DLFC Washer Flow 9 gpm
A-16529	DLFC Washer Flow 10 gpm
A-16735	DLFC Washer Flow 12 gpm
A-16736	DLFC Washer Flow 15 gpm
A-16528	DLFC Washer Flow 20 pm
A-16737	DLFC Washer Flow 25 gpm

# Upper Control Drive

Assembly




Item No.	Quantity	Part No.	Description
1	1	A-07190F	Transformer, 24V, 60Hz, for Mechanical and NX
2	1	A-13547	Strain Relief, Cord, Back Plate
3	2	A-10300	Screw, Hex, Back Plate-Timer
4	1	A-19691	Plug, Back Plate
5*	1		Timer, Mechanical
6	2	A-10302	Insulator, Micro Switch
7	3	A-10218	Micro Switch
8	2	A-14923	Screw, Mirco Switch
9- 14	1	A60160	Drive Cam Assy, AQT-275, 285 & Upper 290
15	1	A-60219	Cover, Valve
16	1	A-60219-01	Cover, Panel, Polycarbonate
17	2	A-10231	Screw, Hex, Bracket Motor
18	1	A-10774	Braket, Motor
19	2	A-10157	Bushing
20	1	A-16044-3G	Gear Drive, AQT-275, 285 & Upper 290
21	1	A-10158	Axis Drive, AQT-275, 285 & Upper 290
22	1	A-16043-3G	Pinion Drive, AQT-275, 285 & Upper 290
23	1	A-10338	Roll Pin
24	3	A-10016S	Screw, Motor Mounting
25	1	A-14923-01	Screw, Mirco Switch Single
26	1	A-12777	Cam, Shut-off Valve
27	1	A-30018F	Motor 24V, AQT-275, 285, 290 Up, 315, 390 Up & Low
28	3	A-02002	Screw
29	1	A-11826-01	Bracket, Brine Valve Side
30	2	A-10299	Screw, Terminal Strip
31	1	A-15226	Terminal Strip
32	1	A-18697	Back Plate
33	4	A-02115	Back Plate, Knob Screw
34	1	A-19048	Cable Gland Connector


# Lower Control Drive

Assembly

PN A-60160-01  
Lower Drive Cam Assy








Item No.	Quantity	Part No.	Description
1	1	A-07190F	Back Plate, AQT-290 Lower
2	1	A-14769	Braket, Motor
3	3	A-10016S	Screw, Motor Mounting
4 - 9	1	A-60160-01	Lower Drive Cam Assy
10	1	A-11805	Screw, Micro Switch
11	1	A-10218	Micro Switch
12	1	A-10302	Insulator, Micro Switch
13	1	A-18724	Window
14	1	A-18708-2	Cover, AQT-290 Lower
15	1	A-18744	Screw, Cover
16	2	A-14430-01	Washer, Window
17	2	A-14430	Screw, Window
18	2	A-11224	Screw, Motor Bracket, AQT-290 Lower
19	1	A-30017F	Motor 24V, AQT-290 Lower
20	1	A-19048	Cable Gland Connector

## 170 Brine System

Assembly



PN 1 - 22 ----- A-60034 --- Brine Valve, Short Stem, Less BLFC, 1/2" for AQT-285  
PN 14 - 22 ----- A-60381 --- Injector Body, 1/2" for AQT-285



Item No.	Quantity	Part No.	Description
1	1	A-15517	Stem Guide, Brine Valve
2	1	A-10250	Retaining Ring
3	1	A-04003F	Washer
4	1	A-15310	Spring, Brine Valve
5	1	A-14797	Stem, Brine Valve
6	1	A-14790	Body, Brine Valve
7	1	A-13201	O-Ring
8	1	A-14785	BLFC, Retainer
9**	1	A-120XX	BLFC, Button
10	1	A-15413-01	Fitting Brine Line
11	1	A-15415	Fitting Insert
12	1	A-15414	Fitting Nut, Brass
13	1	A-15413	Fitting, Elbow
14	1	A-16460	Tube, Brine Valve
15***-16***	1	A-14801-XXC	Injector Assy
17	2	A-10229	Injector Cover Gasket
18	1	A-11893	Injector Cover
19	1	A-14804	Screw, Injector Cover
20	1	A-10227-170	Screen, Injector
21	1	A-17777	Injector, Body
22	1	A-14805	Injector, Body Gasket

** BLFC Button Options	
A-12085	BLFC Button - 1.2 gpm
A-12086	BLFC Button - 1.5 gpm
A-12087	BLFC Button - 2.0 gpm
A-12088	BLFC Button - 2.4 gpm
A-12089	BLFC Button - 3.0 gpm
A-12090	BLFC Button - 3.5 gpm
A-12091	BLFC Button - 4.0 gpm
A-12092	BLFC Button - 5.0 gpm

*** Injectors	
A-14801-03C	Injector Assy, #3C, Yellow (18" & 20" Tank)
A-14801-04C	Injector Assy, #4C, Green (21" Tank)
A-14801-05C	Injector Assy, #5C, White (24" Tank)
A-14801-06C	Injector Assy, #6C, Red (30" and 36" Tank)

## Troubleshooting

Problems, Cause & Corrections



Problem	Cause	Correction
1) Softener fails to regenerate.	A) Electrical service to unit has been interrupted.	A) Assure permanent electrical service (check fuse, plug, pull chain or switch).
	B) Timer is defective.	B) Replace timer.
	C) Power failure.	C) Reset time of day.
2) Hard water.	A) By-pass valve is open.	A) Close by-pass valve.
	B) No salt in brine tank.	B) Add salt to brine tank and maintain salt level above water level.
	C) Injector screen plugged.	C) Clean injector screen.
	D) Insufficient water flowing into brine tank.	D) Check brine tank fill time and clean brine line flow control if plugged.
	E) Hot water tank hardness.	E) Repeated flushing of the hot water tanks required.
	F) Leak at distributor tube.	F) Make sure distributor tube is not cracked. Check O-ring and tube pilot.
	G) Internal Valve Leak.	G) Replace seals and spacers and/or piston.
	H) Service Adapter did not return to service.	H) Check drive motor and switch.
3) Unit used too much salt.	A) Improper salt setting.	A) Check salt usage and salt setting.
	B) Excessive water in brine tank.	B) See problem No. 7.
4) Loss of water pressure.	A) Iron buildup in line to water conditioner.	A) Clean line to water.
	B) Iron buildup in water conditioner.	B) Clean control and add mineral cleaner to mineral bed. Increase frequency of regeneration.
	C) Inlet of control plugged due to foreign material broken loose from pipes by recent work done on plumbing system.	C) Remove piston and clean control.
5) Loss of mineral through drain line.	A) Air in water system.	B) Assure that well system has proper air eliminator control. Check for dry well conditions.
	B) improper size drain line flow control.	B) Check for proper drain rate.
6) Iron in conditioned water.	A) Fouled mineral bed.	A) Check backwash, brine draw and brine tank fill. Increase frequency of regeneration. Increase backwash time.
7) Excessive water in brine tank.	A) Plugged drain line flow control.	A) Clean flow control.
	B) Plugged injector system.	B) Clean injector and screen.
	C) Timer not cycling.	C) Replace timer.
	D) Foreign material in brine valve.	D) Replace brine valve seat and clean valve.
	E) Foreign material in brine line flow control.	E) Clean brine line flow control.

Problem	Cause	Correction
8) Softener fails to draw brine.	A) Drain line flow control is plugged.	A) Clean drain line flow control.
	B) Injector is plugged.	B) Clean injector.
	C) Injector screen plugged.	C) Clean screen.
	D) Line pressure is too low.	D) Increase line pressure to 20 P.S.I.
	E) Internal control leak.	E) Change seals, spacers and piston assembly
	F) Service adapter did not cycle.	F) Check drive motor and switches.
9) Control cycle continuously.	A) Misadjusted, broken or shorted switch.	A) Determine if switch or timer is faulty and replace it or replace complete power head.
10) Drain flows continuously.	A) Valve is not programming correctly.	A) Check timer program and positioning of control. Replace power head assembly if not positioned properly.
	B) Foreign material in control.	B) Remove power head assembly and inspect bore. Remove foreign material and check control in various regeneration positions.
	C) Internal control leak	C) Replace seals and piston assembly.

### General Service Hints for Meter Control

**Problem: Softener delivers hard water**

**Reason:** Reserve capacity has been exceeded.


**Correction:** Check salt dosage requirements and reset program wheel to provide additional reserve.

**Reason:** Program wheel is not rotating with meter output.


**Correction:** Pull cable out of meter cover and rotate manually. Program wheel must move without binding and clutch must give positive clicks when program wheel strikes regeneration stop. If it does not, replace timer.

**Reason:** Meter is not measuring flow.


**Correction:** Check meter with meter checker.



**Meter control valve**



**Timer, meter - timer control valve**



## System #4 Immediate/Delayed Regeneration Valve Wiring


<b>TM</b>	Time Motor
<b>VDM</b>	Valve Drive Motor
<b>SW1</b>	Timer Homing Switch
<b>SW2</b>	Timer Program Switch
<b>SW3</b>	Valve Homing Switch
<b>SW4</b>	Valve Step Switch
<b>SW5</b>	Brine Cam Switch
<b>THCAM</b>	Timer Homing Cam
<b>TPCAM</b>	Timer Program CAM
<b>HCAM</b>	Valve Homing Cam
<b>SCAM</b>	Valve Step Cam
<b>BVCAM</b>	Brine Valve Cam
<b>LDCAM</b>	Lower Drive Cam

**Note:**

1. Single tank time clock, meter delayed, or meter immediate regeneration.
2. Valve shown in service position.

**NOTES:**

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.



**AQUATROL** | P.O. Box 2235 Chino Hills, CA 91709 • USA