


AQT-910XT / AQT-950XT


ELECTRONIC VALVES SERIES



PROGRAMMING MANUAL

TABLE OF CONTENTS

General Installation Instructions	3
AQT-XT Keypad	4
XT Programming	5
- Basic Settings	5
- Password Settings	7
- Advanced Settings	8
Regeneration Information	13
Historical Information	14
XT Features	16
- Backup Battery	16
- Bypass	16
- Power Outage	16
- Optional DP Switch Signal Output	16
Maintenance	17
- Maintenance Reminder	17
- Manual Immediate Regeneration	17
- System Errors	17
- Reset	18
- Restore Factory Settings	18
AQT-910/950XT Control Head Assembly & Parts List	19
AQT-910XT Body Assembly	20
AQT-910XT Body Parts List	21
AQT-950XT Body Assembly	22
AQT-950XT Body Parts List	23
Controller Wiring Diagram	24
AQT-910XT Dimensional Drawings	25
AQT-950XT Dimensional Drawings	26
Troubleshooting	27

 WARNINGS	DO NOT EXCEED 120 PSI WATER PRESSURE
	DO NOT EXCEED 100°F WATER TEMPERATURE
	DO NOT SUBJECT UNIT TO FREEZING CONDITIONS
	CALIFORNIA PROPOSITION 65 WARNING <small>THIS PRODUCT CONTAINS CHEMICALS KNOWN TO THE STATE OF CALIFORNIA TO CAUSE CANCER OR BIRTH DEFECTS OR OTHER REPRODUCTIVE HARM.</small>

PLEASE READ THIS MANUAL IN ITS ENTIRETY AND FOLLOW ALL THE INSTRUCTIONS BEFORE INSTALLATION AND OPERATION.

Water Pressure	Minimum 20 - 25 PSI
Electrical Supply	Input: 100-240 VAC 50/60 Hz, Output: 12V DC/1A
Existing Piping	Free of any deposits or build-ups inside pipes (iron, scale, etc...)
Softener Placement	Locate close to drain and connect according to plumbing codes
Bypass Valves	Always provide for bypass valve if unit is not equipped with one

Installation Instructions


1. Place the softener tank where you want to install the unit making sure the unit is level and on a firm base. *Maximum 4 feet apart for twin units.*
2. All plumbing should be done in accordance with local plumbing codes. The pipe size for the drain line should be the same size as the drain line flow control female connection. Water meters are to be installed on soft water outlets. Twin units with (1) one meter shall be installed on common soft water outlets of units.
3. Lubricate the distributor O-ring seal and tank O-ring seal. Place the main control valve on tank. *(Only use silicone lubricant).*
4. Solder joints near the drain must be done prior to connecting the Drain Line Flow Control fitting. Leave at least 6" between the DLFC and solder joints when soldering when the pipes are connected on the DLFC. Failure to do this could cause interior damage to the DLFC.
5. Teflon tape is the only sealant to be used on the drain fitting. The drain from twin units may be run through a common line.
6. Make sure that the floor is clean beneath the salt storage tank and that it is level
7. Place approximately 1" of water above the grid plate *(if used)* in your salt tank. Salt may be place in the unit at this time.
8. On units with by-pass, place in by-pass position. Turn on main water supply. Open a cold soft water tap nearby and let run a few minutes or until the system is free from foreign material *(usually solder)* that may have resulted from the installation.
9. Place the by-pass in service position.
10. Manually index the softener control into "service" position and let water flow into the mineral tank. When water flow stops, open a cold water tap nearby and let run until air pressure is relieved.
11. Electrical: All electrical connections must be connected according to codes. Use electrical conduit if applicable. *(See Wiring Diagram section for more information).*
12. Plug into power supply.

WARNINGS

- The information, specifications and illustrations in this manual are based on the latest information available at the time of release. The manufacturer reserves the right to make changes at any time without notice.
- This manual is intended as a guide for service of the valve only. System installation requires information from a number of suppliers not known at the time of manufacture. This product should be installed by a plumbing professional.
- This unit is designed to be installed on potable water system only.
- This product must be installed in compliance with all state and municipal plumbing and electrical codes. Permits may be required at the time of installation.
- It is established that when daytime water pressure exceeds 80 psi (5.5 bar), the maximum pressure rating of 125 psi (8.6 bar) can be exceeded. A pressure regulator must be installed on this system or warranty is voided.
- Do not install the unit where temperatures may drop below 32 °F (0 °C) or above 125 °F (52 °C).
- Do not place the unit in direct sunlight. Black units will absorb radiant heat increasing internal temperatures.
- Do not strike the valve or any of the components.
- Warranty of this product extends to manufacturing defects. Misapplication of this product may result in failure to properly condition water, or damage to product.
- A prefilter should be used on installations in which free solids are present.
- In some applications local municipalities treat water with Chloramines. High Chloramine levels may damage valve components.
- Correct and constant voltage must be supplied to the controller to maintain proper function.
- An interrupted alternating current (120 VAC) supply is required.
- The system is not designed to withstand extreme humidity or water spray from below.
- Always provide for the installation of a bypass valve if unit is not equipped with one.

AQT-XT

Keypad



1. Current Time
2. Edit
- When control valve in data setting
3. Unit Status
- ▲ Regeneration
- ✕ Service
4. Unit
- UNIT 1: valve head
- UNIT 2: in/out head
5. Flow Meter
6. Enter
7. Basic Setup
8. Up Button
9. Time Of Day
- AM or PM
10. Day of Week
11. Grain Unit
- Grs = Total Resin Exchange Capacity
12. Gallon Unit
- GAL = Flowrate
13. Hardness unit
- Grs&GAL = Water Hardness
14. Cycle Button
15. Down Button



Basic Set Up Button



Enter Button

- Confirm and save the current setting
- Basic information query



Up Button

- Increase or cycle



Down Button

- Decrease or cycle



Cycle

- Previous step / Manual regeneration



To Enter Advanced Settings

- Press and hold simultaneously for 3 seconds the ENTER and UP buttons.



To Enter Historic Information

- Press and hold simultaneously for 3 seconds the UP and DOWN buttons.

1. Enter Basic Settings



Press BASIC SET UP Button to enter Basic Settings.



2. Set Hour


Press UP or DOWN to edit,



then press ENTER to save.



Flashing



Default: 12

Range: 00 - 12

3. Set Minutes

Press UP or DOWN to edit,



then press ENTER to save.



Flashing



Default: 00

Range: 00 - 59

4. Set Time of Day


Press UP or DOWN to edit,



then press ENTER to save.



Flashing



Default: AM

Range: AM/PM

XT Programming

Basic Settings Cont.

5. Set Day of Week

Press UP or DOWN to edit,



then press ENTER to save.



Flashing



Default: AM

Range: Mon - Sun

Mon = Monday

Tue = Tuesday

Wed = Wednesday

Thu = Thursday

Fri = Friday

Sat = Saturday

Sun = Sunday



6. Set Feed Water Hardness

Press UP or DOWN to edit,



then press ENTER to save.



Flashing

Default: 20 Grains/gallon

Range: 1 - 999 Grains/gallon



The treated water capacity is automatically calculated. Then the display will only be shown for SOF3 or SOF4.

Done

1. Password Setup

In service position, press UP for 3 seconds to enter.



Default Password: 0000



2. Input Password

Press UP or DOWN to edit a new password



then press ENTER to save.



Flashing

Default: 0000

Range: 0000 - 9999



XT Programming

Advanced Settings

1. Enter

Simultaneously press and hold ENTER & UP for 3 seconds to enter,



then press ENTER to input password.



Default: N/A

Range: N/A

2. Input Password

Press UP or DOWN to edit a new password



then press ENTER to save.



Flashing


Default: 0000

Range: 0000 - 9999

Original password: 0000

3. Wrong Password

Error is displayed and an alarm will go off.



If an invalid password is entered an error alarm will go off for one second, then the screen will display an Error message and will return to service position.

4. Set Treated Water Capacity

Press UP or DOWN to edit,



then press ENTER to save.



Flashing

Default: N

Range: N
Y

If "N" was chosen - Manually set the treated water capacity.

If "Y" was chosen - Automatically calculate the treated water capacity by controller.

4.a. Set the Treated Water Capacity (If "N" was chosen in step 4)

Press UP or DOWN to edit,



then press ENTER to save.



Flashing

Default: 5400

Range: 1 - 99999 Gallons

4.b.1 Set the Feed Water Hardness (If "Y" was chosen in step 4)

Press UP or DOWN to edit,



then press ENTER to save.



Flashing

Default: 20 Grains/gallon

Range: 1 - 999 Grains/gallon

4.b.2 Set the Total Resin Exchange Capacity

Press UP or DOWN to edit,



then press ENTER to save.



Flashing

Default: 106 x 1000 Grains

Range: 1 - 9999 x 1000 Grains

4.b.3 Auto-Calculated Value Display

This screen is not editable.




5. Set Backwash Time

Press UP or DOWN to edit,



then press ENTER to save.



Flashing

Default: 15 min

Range: 0 - 999 min

XT Programming

Advanced Settings Cont.

6. Set Brine Draw Time

Press UP or DOWN to edit,



then press ENTER to save.



Flashing

Default: 60


Range: 0 - 999 min

7. Set 2nd-Backwash Time

Press UP or DOWN to edit,



then press ENTER to save.



Flashing

Default: 0

Range: 0 - 999 min

8. Set Rinse Time

Press UP or DOWN to edit,



then press ENTER to save.



Flashing

Default: 10 min

Range: 0 - 999 min

9. Set Auto-Refill

Press UP or DOWN to edit,



then press ENTER to save.



Flashing

Default: N

Range: N
Y

If "N" was chosen -
It means refill time is manually input and
then continue with step 9.a.

If "Y" was chosen -
It indicates the refill time is automatically
calculated by the controller and then
continue with step 10.b.1.

9.a. Set Refill Time (If "N" was chosen in step 9)

Press UP or DOWN to edit,



then press ENTER to save.



Then return to service position.



Flashing

Default: 12

Range: 0 - 999 min

9. b.1. Set Salt Consumption per cu.ft Resin (If "Y" was chosen in step 9)

Press UP or DOWN to edit,



then press ENTER to save.



Flashing

Default: 10

Range: 0.1 - 99.9 min

9. b.2. Set Total Resin Amount (ft³)

Press UP or DOWN to edit,



then press ENTER to save.



Flashing

Default: 1.76

Range: 0 - 99.99

9.b.3. Set BLFC (gpm)

Press UP or DOWN to edit,



then press ENTER to save.



Flashing

Model:	910XT	950XT
--------	-------	-------

Default:	0.25	3.0
----------	------	-----

Range:	0.25	1.0
	0.5	2.0
	1.0	3.0
		4.0
		5.0

XT Softener Settings

Advanced Settings Cont.

9.b.4. Display the Auto Refill Time

This data is calculated by the control valve and it is not editable.

Press ENTER to return to service position.



10. Set Maintenance Time (Week)



Press UP or DOWN to edit,



then press ENTER to save and return to service position.



Default: 78

Range: 0, 26, 52, 78

"0" indicates this function is off.



When the valve reaches the set weeks for maintenance, valve must be serviced by a certified professional.

Done

Regeneration Information


AQT-910XT & AQT-950XT Valves

1. Regeneration Information



Only while system is in regeneration, press ENTER to check remaining time of the cycle step in process.



Valve #1 in service, while valve #2 in regeneration.



Remaining time of cycle step in process will be shown.



Same information for the next cycle steps.

Historical Information

AQT-910XT & AQT-950XT Valves

1. View Historical Information

In Service Position, press UP and DOWN for 3 seconds to enter and query.



then press ENTER to check the next Item.



1.a. Check the Current Flow (GAL/min)

Press ENTER to check the Current flow.



Units: GAL = Gallons/min

1.b. Check the Peak Flow (GAL/min)

Then press ENTER again to check the Peak flow.



Units: GAL = Gallons/min

1.c. Check the Total Flow After Installation


Press ENTER again to check the Total Flow after installation.



Units: Gallons

1.d. Check the Total Use Time After Installation

Press ENTER again to check the Total Use Time after installation.



Units: h = hours

1.e. Check the Total Regeneration Times After Installation

Press ENTER again to check the total regeneration times after installation



Units: Regeneration times



1.f. Remaining Days for Next Maintenance

Press BASIC SET UP Button to reset maintenance days period.



Units: d = days



Return to service position.

XT Features


AQT-910XT & AQT-950XT Valves

1. Backup Battery

Remove the front cover and connect the battery with connectors.




Battery Model: 6LR619V

 It is suggested that the battery be connected after the valve has been installed to protect the battery.

2. Bypass (Only AQT-910XT)

Rotate the handles to adjust the bypass position.



3. Power Outage


- 3.1 When a power outage happens while valve is in service position, the control valve will keep in the same position when the power is restored.
- 3.2 If a power outage happens in any regeneration cycles, once the power is restored, the control valve will automatically look for the target position when the power outage happened. Then it will continue to complete the regeneration steps.
- 3.3 If the power outage happens when the control valve is moving from one position to the other, once the power restored, it will look for the target position when the power outage happened. Then it will continue to complete the regeneration steps.

4. Optional DP Switch Signal Input

The valve has reserved one interface for DP input for receiving a remote signal. If DP switch is closed for more than 30 seconds, a regeneration will occur immediately. See Controller Wiring Diagram on page 24 to connect DP.

1. Maintenance Reminder

When it is time for maintenance, the display will automatically remind the user to call for maintenance.



2. Manual Immediate Regeneration

While in Service Position, press and hold CYCLE Button for 5 seconds. The control valve will initiate an immediate regeneration.

Press the CYCLE Button to jump to the next cycle step. A system queued regeneration can only be cleared by stepping through the regeneration process step by step.



3. System Errors

The control valve will automatically display and alarm any detected system errors. The detailed information is as follows:

UPPER PISTON ERRORS:

- 1. Upper piston can not locate the service position.
- 2. Upper piston optical sensor no signal.
- 3. Upper piston electric motor stalled or locked.
- 4. Upper piston wrong service position.



LOWER PISTON ERRORS:

- 1. Lower piston can not locate the service position.
- 2. Lower piston optical sensor no signal.
- 3. Lower piston electric motor stalled or locked.
- 4. Lower piston wrong service position.



Maintenance

AQT-910XT & AQT-950XT Valves Cont.

4. Reset

If any Error alarm occurs on the screen.


Simultaneously press the UP and CYCLE Buttons and hold for 3 seconds to reset.



Upper piston resetting



Lower piston resetting

 If reset is successful the error alarm will disappear and it will return to the position where the error occurred. Otherwise, call a professional for more help.

8. Restore Factory Settings

While the valve is unplugged, press and hold the BASIC SET UP Button, then plug in the valve.



Upper piston resetting



Lower piston resetting


Release the BASIC SET UP Button,



The parameters of the valve will be restored back to factory default settings. Valve #1 (upper piston) will return to SERVICE position and Valve #2 (lower piston) will return to STAND-BY position.

AQT-910XT/AQT-950XT Control


Assembly & Parts List



Item No.	Quantity	Part No.	Description
1	1	A-90014	Valve Cover, 910/950
2	1	A-90018-910	Electronic Board, AQT-910XT
		A-90018-950	Electronic Board, AQT-950XT
3	1	A-90017	Motor for XT, 12V, AQT-910/950
4	1	A-70016	Pinion Gear
5	1	A-70015	Screw
6	4	A-90025	Backplate, 910/950
7	1	A-70013	Screw
8	1	A-90012	Optical Sensor, AQT-910/950
9	1	A-70024	Transformer, 12V, AQT-580/581/910/950

AQT-910XT Body

Assembly



AQT-910XT Body


Parts List

Item No.	Quantity	Part No.	Description
1	1	A-91001-100	Body, AQT-910XT, 2.5" base
2	1	A-91002-01	Seals and Spacers Stack, AQT-910XT, Upper
3	1	A-91003-01	Piston Assy, AQT-910XT, Upper
4	1	A-91004-01	Piston Sleeve, AQT-910XT, Upper
5	2	A-91005	O-ring, End Plug, AQT-910XT (2 pieces kit)
6	2	A-91006	Gear Bracket, Upper & Lower
7	2	A-91007	Control Gear, Upper & Lower
8	8	A-91008	Screw, Gear Bracket
9	1	A-91002-02	Seals and Spacers Stack, AQT-910XT Lower
10	1	A-91003-02	Piston Assy, AQT-910XT, Lower
11	1	A-91004-02	Piston Sleeve, AQT-910XT, Lower
12	2	A-91009	Seal Ring, 2.5" Base
13	2	A-91010	O-ring, Valve Base (2.5" Base)
14	2	A-91011	O-ring, Riser Pipe (2.5" Base)
15	1	A-50011	Locking clip, Drain QC
16	1	A-91013	BLFC Retainer
17	1	*	BLFC (must see BLFC Table)
18	1	**	DLFC (must see DLFC table)
19	1	A-56247	Drain, QC, 1/2" Tubing
20 & 21	1	A-13244	Brine Line, QC, 3/8" Tubing
22	1	***	Injector Assy (Must See Injector Table)
23	1	A-91014	Injector Plug
24	2	A-91015	1" PVC Tube (2 pieces)
25	4	A-91016	Quick Adapters, Straight, 1" (4 pcs kit), AQT-910
26	1	A-91017	In/Out 2nd Tank Head
27	2	A-91018	In/Out 1" Straight Connector, Main Valve (2 pieces kit)
28	1	A-91019	Flow Screen
29	1	A-91020	Turbine Meter Assy, AQT-910XT Valves

* BLFC Button Options	
A-12094	BLFC Button - 0.25 gpm
A-12095	BLFC Button - 0.5 gpm
A-12097	BLFC Button - 1.0 gpm
** DLFC Button/Washer Options	
A-12085	DLFC Button - 1.2 gpm
A-12084	DLFC Button - 1.5 gpm
A-12087	DLFC Button - 2.0 gpm
A-12088	DLFC Button - 2.4 gpm
A-12089	DLFC Button - 3.0 gpm
A-12090	DLFC Button - 3.5 gpm
A-12091	DLFC Button - 4.0 gpm
A-12092	DLFC Button - 5.0 gpm
A-12098	DLFC Button - 7.0 gpm
*** Injector Options	
A-10225-0-N	Injector Assy, #0, Red
A-10225-1-N	Injector Assy, #1, White
A-10225-2-N	Injector Assy, #2, Blue
A-10225-3-N	Injector Assy, #3, Yellow

AQT-950XT Body

Assembly



AQT-950XT Body


Parts List

Item No.	Quantity	Part No.	Description
1	1	A-95001-150	Body, AQT-950XT, 4" base
2	1	A-95002-01	Seals and Spacers Stack, AQT-950XT, Upper
3	1	A-95003-01	Piston Assy, AQT-950XT, Upper
4	1	A-95004-01	Piston Sleeve, AQT-950XT, Upper
5a	2	A-95005	O-ring, End Plug, AQT-950XT (2 pieces kit)
5	2	A-95006	Gear Bracket, Upper & Lower
6	2	A-91007	Control Gear, Upper & Lower
7	8	A-95008	Screw, Gear Bracket
8	1	A-95002-02	Seals and Spacers Stack, AQT-950XT Lower
9	1	A-95003-02	Piston Assy, AQT-950XT, Lower
10	1	A-95004-02	Piston Sleeve, AQT-950XT, Lower
11	4	A-95009	Base, Screw
12	2	A-95010	O-ring, Valve Base (4.0" Base)
13	2	A-95011	O-ring, Riser Pipe (4.0" Base)
14	1	A-90247	Drain Connector, 1", Straight
15	1	A-71019	DLFC Retainer
16	1	**	DLFC (must see DLFC table)
17	1	A-71014	U Clip, Red, Brine and Injector
18	1	A-71016	BLFC Retainer
19	1	*	BLFC (must see BLFC Table)
20	1	A-71013-12	Brine Connector, 1/2", Elbow
21	2	A-95016	Quick Adapters, Male, Body, 1.5" (2 pcs kit)
22	2	A-95015	1" PVC Tube (2 pieces)
23	2	A-95016-M	Quick Adapters, Plain, 2nd Head, 1.5" (2 pcs kit)
24	1	A-95017	In/Out 2nd Tank Head, 1.5"
25	1	***	Injector Assy (Must See Injector Table)
26	1	A-95020	Turbine Meter Assy, AQT-950XT Valves
27	1	A-95019	Flow Screen
28	2	A-95018	In/Out 1.5" Straight Connector, Main Valve (2 pieces kit)



* BLFC Button Options	
A-71015-01	BLFC Button, 1.00 gpm
A-71015-02	BLFC Button, 2.00 gpm
A-71015-03	BLFC Button, 3.00 gpm
A-71015-04	BLFC Button, 4.00 gpm
A-71015-05	BLFC Button, 5.00 gpm
** DLFC Button/Washer Options	
A-17938	DLFC Washer Flow 2.4 gpm
A-17939	DLFC Washer Flow 3.2 gpm
A-17940	DLFC Washer Flow 3.5 gpm
A-17941	DLFC Washer Flow 4 gpm
A-17942	DLFC Washer Flow 5 gpm
A-17943	DLFC Washer Flow 8 gpm
A-17944	DLFC Washer Flow 9 gpm
A-16529	DLFC Washer Flow 10 gpm
A-16735	DLFC Washer Flow 12 gpm
A-16736	DLFC Washer Flow 15 gpm
A-16528	DLFC Washer Flow 20 pm
A-16737	DLFC Washer Flow 25 gpm
A-16738	DLFC Washer Flow 32 gpm
*** Injector Options	
A-12540-3	Injector, #3, White
A-12540-4	Injector, #4, Green
A-12540-5	Injector, #5, Blue

AQT-910XT/AQT-950XT



Controller Wiring



AQT-910XT
Dimensional Drawing



AQT-950XT
Dimensional Drawing



Troubleshooting

Problems, Cause & Corrections

Problem	Cause		Correction	
1) The control fails to regenerate automatically.	A)	Disconnected meter cable.	A)	Reconnect the meter cable.
	B)	Transformer damaged.	B)	Replace the transformer.
	C)	Electronic controller or sensor damaged.	C)	Replace or repair.
2) The treated water hardness is higher than setting.	A)	Bypass valve is not in service position.	A)	Adjust the bypass valve to service position.
	B)	The inlet and outlet water pipe are installed in reverse.	B)	Install the water inlet and water outlet pipe correctly.
	C)	The raw water hardness is higher than setting.	C)	Reset the inlet hardness.
	D)	Resin is polluted and invalid.	D)	Contact a professional to change the resin.
	E)	Brine concentration or quantity.	E)	Keep brine tank full of salt at all times. Clean it yearly. If using a salt grid plate, insure refill water is above the grid plate.
3) Softener fails to brine draw.	A)	Plugged drain line or BLFC.	A)	Clean drain line and flow control.
	B)	Plugged injector.	B)	Clean or replace the injector and screen.
	C)	No water in the brine tank.	C)	Check for blockage in BLFC. Ensure Safety float is not stuck.
4) Salty taste for treated water.	A)	Low pressure for inlet water.	A)	Install booster pump to increase pressure of inlet water.
	B)	Drainage pipeline is blocked.	B)	Clean up the blockage.
5) Continuous flow to drain.	A)	Internal control leak.	A)	Contact a professional to repair.
	B)	Piston jammed with brine.	B)	

